

# HYTORC

## TOOL MODEL: HY-4XLCT W/ HEX LINK PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart ( For Serial Number F3496 & Higher)

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	580	80	786	104
1600	618	85	838	110
1800	694	96	941	124
2000	770	106	1044	138
2200	847	117	1148	152
2400	924	128	1253	165
2600	1001	138	1357	179
2800	1078	149	1461	193
3000	1155	160	1566	207
3200	1232	170	1670	220
3400	1309	181	1774	234
3600	1386	192	1879	248
3800	1463	202	1983	262
4000	1540	213	2088	276
4200	1624	225	2201	290
4400	1708	236	2315	303
4600	1792	248	2429	317
4800	1876	259	2543	331
5000	1960	271	2657	345
5200	2031	281	2753	358
5400	2102	291	2849	372
5600	2173	301	2946	386
5800	2244	310	3042	400
6000	2315	320	3138	414
6200	2392	331	3243	427
6400	2469	341	3347	441
6600	2546	352	3451	455
6800	2623	363	3556	468
7000	2700	373	3660	482
7200	2777	384	3765	496
7400	2854	395	3869	510
7600	2931	405	3973	524
7800	3008	416	4078	538
8000	3085	427	4182	552
8200	3163	437	4288	565
8400	3241	448	4393	579
8600	3319	459	4499	593
8800	3397	470	4605	607
9000	3475	481	4711	620
9200	3551	491	4814	634
9400	3627	502	4917	648
9600	3703	512	5020	662
9800	3779	523	5123	676
10000	3855	533	5226	690

# IMPORTANT SAFETY INSTRUCTIONS

**WARNING:** Your **HYTORC TORQUE MACHINE** is a power tool, and as with any power tool, certain safety precautions should be observed to avoid accidents or personal injury. The following tips will assist you.

- **READ ALL INSTRUCTIONS.**
- **KEEP WORK AREA CLEAN AND WELL LIT.**
- **CONSIDER WORK AREA ENVIRONMENT.** Electrical Pumps should never be used in an atmosphere which can be considered potentially volatile. If there is any doubt, use an air pump. Also Note: metal to metal contact can cause sparks, precautions should be taken.
- **AVOID PREMATURE TOOL STARTING.** The Pump Remote Control is for the **TOOL OPERATOR** only.
- **STAY CLEAR DURING OPERATION.** In most cases, the tool will allow “hands free” operation. If the tool must be held or steadied during operation, use alternative means of securing the tool to the application
- **GUARD AGAINST ELECTRIC SHOCK.** Ensure the pump is properly grounded and the proper voltage is being used.
- **STORE IDLE TOOLS.** When not in use, tool and accessories should be properly stored to avoid deterioration
- **USE RIGHT TOOL.** Don't force small tools or attachments to do the job of a larger tool. Don't use a tool for purposes not intended.
- **PROPER SAFETY ATTIRE.** When handling/operating hydraulic equipment use work gloves, hard hats, safety shoes and other applicable clothing.
- **USE SAFETY GLASSES.**
- **MOVING EQUIPMENT.** Do not use hydraulic hoses, uni-swivels, pump power or remote cords as means of moving the equipment.
- **MAINTAIN TOOLS WITH CARE.** For top performance, inspect tools, powerpack and accessories for visual damage frequently and always prior to use. Always follow instruction for proper tool and pump maintenance. Refer to the Operations Maintenance Section for further clarification
- **STAY ALERT.** Watch what you are doing. Use Common sense. Do not use power equipment under the influence of any mood altering substances.
- **PRIOR TO OPERATION**  
Ensure that all hydraulic connections are securely connected and there is no leakage  
Verify that the Hydraulic hoses are not kinked or otherwise damaged.  
Ensure the square drive and its retainer are fully and securely engaged.  
Be certain that all connectors, elbows, fitting and swivels are not bent, loose or damaged.
- **PRIOR TO USE.**  
Check sockets for size, quality and flaws. (Do not use if questionable)  
Cycle tool to ensure proper function.  
Locate a solid, secure reaction point.  
Be sure the reaction arm retaining clamp is fully engaged.  
Be sure the hydraulic hoses are free of the reaction point.  
Pressurize the system momentarily; if the tool tends to “ride up” or to “creep”, stop and re-adjust the reaction arm to a more solid and secure position.

**NOTE:** Remain clear of the reaction arm during operation and never put body parts between reaction arm and reaction surfaces.

- **ALWAYS USE QUALITY ACCESSORIES.** Always use top quality impact sockets in good condition which are the correct size and fully engage the nut. Hidden flaws, however, remain a possibility which could cause breakage, so stay clear of sockets during operation
- **DO NOT USE** other equipment to enhance performance (Hammer on Socket/Tool)

**NOTE:** Hytorc Pumps are designed to operate Hytorc Tools only. Damage may occur to the pump or the product that is being operated due to misuse.

## SAVE THESE INSTRUCTIONS FOR FUTURE USE!