

HYTORC

TOOL MODEL: HY-15MXT PRESSURE/TORQUE CONVERSION CHART

Standard Torque Chart

PRESSURE IN PSI	TORQUE IN			PRESSURE IN BAR
	FT. LBS.	KGM	NM	
1500	2268	314	3075	104
1600	2423	335	3285	110
1800	2733	378	3704	124
2000	3042	421	4124	138
2200	3351	463	4542	152
2400	3659	506	4960	165
2600	3967	549	5378	179
2800	4276	591	5796	193
3000	4584	634	6214	207
3200	4892	677	6632	220
3400	5201	719	7050	234
3600	5509	762	7468	248
3800	5817	805	7886	262
4000	6126	847	8304	276
4200	6437	890	8726	290
4400	6749	933	9149	303
4600	7060	976	9571	317
4800	7372	1020	9993	331
5000	7683	1063	10415	345
5200	7995	1106	10838	358
5400	8307	1149	11262	372
5600	8620	1192	11685	386
5800	8932	1235	12108	400
6000	9244	1278	12531	414
6200	9557	1322	12955	427
6400	9869	1365	13379	441
6600	10182	1408	13803	455
6800	10495	1451	14227	468
7000	10808	1495	14651	482
7200	11114	1537	15066	496
7400	11419	1579	15480	510
7600	11725	1622	15895	524
7800	12031	1664	16309	538
8000	12337	1706	16723	552
8200	12648	1749	17146	565
8400	12960	1792	17569	579
8600	13272	1836	17991	593
8800	13584	1879	18414	607
9000	13896	1922	18837	620
9200	14196	1963	19244	634
9400	14497	2005	19652	648
9600	14797	2046	20059	662
9800	15098	2088	20467	676
10000	15399	2130	20874	690